
## CONNECTION OF JTL RL270 PROTOCOL CONVERTER TO CBISS GASLEAK MONITOR (ARMS1 - RS232) USING EXISTING B+B SMARTWORX RS232 TO RS422/RS485 CONVERTER



1

**ORIGINAL ISSUE** 

RMSJ

10/18