

CONTENTS

1. Jnet NETWORK IDENTIFICATION	2
2. PRESSURES	2
2.1 LT SUCTION PRESSURE	2
2.2 HT SUCTION PRESSURE	2
2.3 SATELLITE SUCTION PRESSURE	2
2.4 DISCHARGE PRESSURE	3
3. TEMPERATURES	3
4. SUCTION PRESSURE CONTROL	4
4.1 LT SUCTION PRESSURE CONTROL	4
4.2 HT SUCTION PRESSURE CONTROL	5
4.3 SATELLITE SUCTION PRESSURE CONTROL	6
5. COMPRESSOR CONTROL	6
5.1 COMMON DATA	6
5.2 COMPRESSOR DATA	7
6. INVERTER DATA	8
7. DISCHARGE PRESSURE CONTROL	9
8. CONDENSER CONTROL	10
8.1 STEP CONTROL	10
8.2 ANALOGUE CONTROL	10
8.3 CONDENSER INPUT & OUTPUT STATUS	11
9. INPUTS AND OUTPUTS	12
10. DEFROST CONTROL	13
10.1 COMMON DATA	13
10.2 DEFROST DATA	14
11. DISPLAY FUNCTIONS	16
12. CLOCK CALENDAR	16
13. RESTORE FACTORY DEFAULTS	17
14. RESTORE PARAMETERS FROM NETWORK	17
15. SYSTEM ALARMS	17
16. DIAGNOSTIC & TEST FUNCTIONS	19
DISPLAY DATA	20

JTL COMPRESSOR PACK ITEM NUMBERS						EP6U (EP6HD)
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
1. Jnet NETWORK IDENTIFICATION						
0	Unit type	EP6U	Unit type			
19	Software version number					
1	Unit number				0.1 - 899.9	
2. PRESSURES						
Note: Pressures can be displayed on the maintenance unit in psi, bar or kPa. The choice is made on item 179. All setpoint ranges are shown in psi.						
Average pressures are averaged over last hour and are updated every 4 minutes.						
179	Pressure display unit choice	PSI bAr PASC	p.s.i. bar kPa		1 - 3	PSI
2.1 LT SUCTION PRESSURE						
21	LT suction pressure					
146	Average LT suction pressure					
42	High LT suction pressure alarm level				10 - 50	20
121	LT pressure transducer selection	OFF Lt.En	Disabled Enabled		0 - 1	Lt.En
126	Absolute LT suction pressure transducer selection	Lt.GA Lt.Ab	Gauge (0 to 100 psi) Absolute (-15 to 85 psi)		0 - 1	Lt.GA
2.2 HT SUCTION PRESSURE						
22	HT suction pressure					
147	Average HT suction pressure					
52	High HT suction pressure alarm level				15 - 80	60
122	HT pressure transducer selection	OFF Ht.En	Disabled Enabled		0 - 1	Ht.En
2.3 SATELLITE SUCTION PRESSURE						
24	Satellite suction pressure					
149	Average satellite suction pressure					
72	High Satellite suction pressure alarm level				20 - 80	50
124	Satellite pressure transducer selection	OFF St.En	Disabled Enabled		0 - 1	St.En
129	Absolute Satellite suction pressure transducer selection	St.GA St.Ab	Gauge (0 to 100 psi) Absolute (-15 to 85psi)		0 - 1	St.GA

JTL COMPRESSOR PACK ITEM NUMBERS						EP6U (EP6HD)					
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE					
				4321							
2.4 DISCHARGE PRESSURE											
Note, EP6U uses a pressure transducer with a full scale range of 0 - 300 psi. EP6HD uses a transducer with a range 0 - 500 psi.											
23	Discharge pressure										
148	Average discharge pressure										
62	High discharge pressure alarm level			EP6U							
				140 - 300	250						
				EP6HD							
				140 - 350	315						
123	Discharge pressure transducer selection	OFF DS.En	Disabled Enabled		0 - 1	DS.En					
3. TEMPERATURES											
Note: Temperatures can be displayed on the maintenance unit in degrees Celsius or Fahrenheit. The choice is made on item 178. All setpoint ranges are shown in Celsius.											
178	Temperature display unit choice	CELS FAhr	Celsius Fahrenheit		0 - 1	CELS					
31	Suction gas temperature										
131	Suction temperature	OFF t1.En	Not selected Selected		0 - 1	t1.En					
32	Discharge temperature										
132	HT suction temperature	OFF t2.En	Not selected Selected		0 - 1	t2.En					
33	Discharge temperature										
133	Discharge temperature	OFF t3.En	Not selected Selected		0 - 1	t3.En					
34	Satellite suction gas temperature										
134	Satellite suction temperature	OFF t4.En	Not selected Selected		0 - 1	t4.En					
35	Subcooled liquid temperature										
135	Subcooled liquid temperature	OFF t5.En	Not selected Selected		0 - 1	t5.En					
36	Saturated gas temperature										
136	Saturated gas temperature	OFF t6.En	Not selected Selected		0 - 1	t6.En					
37	Plant room temperature										
137	Plant room temperature	OFF t7.En	Not selected Selected		0 - 1	t7.En					
157	Refrigerant type (v0.01.0 on)	0 1 2 3 4 5 6 7	nonE 422d 422A 404 407A 407B 507 408A	R422D R422A R404 R407A R407B R507 R408A	0 - 7	nonE					

JTL COMPRESSOR PACK ITEM NUMBERS					EP6U (EP6HD)	
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
897	Site temperature (from broadcast v0.01.0 on)					
898	Site relative humidity (from broadcast v0.01.0 on)					
896	Site absolute humidity (from broadcast v0.01.0 on)					
899	Outside temperature (from broadcast v0.01.0 on)					
4. SUCTION PRESSURE CONTROL						
If suction pressure optimisation is selected then the suction pressure setpoints as set in item 40, 50 and 70 can be adjusted upwards to the maximum by a JTL optimisation unit connected to the network.						
If there is no JTL optimisation unit on the network then the setpoint remains at the original set value. In the event of network failure the setpoints revert to the original set value after a time delay of 15 minutes.						
150	Select network optimised suction pressure control	oFF OPt.E	Not added Selected		0 - 1	oFF
195	Enable low suction pressure safety (v0.00.8 on)	oFF LP.En	Disabled Enabled		0 - 1	oFF
4.1 LT SUCTION PRESSURE CONTROL						
Note, LT suction control is enabled only when there are LT compressors selected in section 5.2 using item 2x5.						
40	LT suction pressure setpoint				- 5 to + 20	4
151	Optimised LT suction setpoint					
152	Optimised LT suction setpoint upper limit				5 - 20	10
43	LT suction pressure deadband				0 - 5	2
44	LT suction pressure increase time constant				1 - 60	30
45	LT suction pressure decrease time constant				1 - 60	15
46	Suction pressure to hold off stage 2				50 - 100	80
47	Suction pressure to hold off stage 3				30 - 100	60
48	LT suction 1st stage hold on				- 8 to +20	0
191	Integrated LT pressure error					
41	No of LT suction steps loaded					
196	Low LT suction pressure safety shutdown level (v0.00.8 on)				-5 to 10	0
49	LT suction total capacity loaded (in kW)					
181	LT suction increase next step (kW)					
182	LT suction decrease next step (kW)					
204	Forced number of LT suction stages				0 - 40	
101	Maximum number of LT compressors allowed				1 - 10	10
102	Number of LT compressors running					

JTL COMPRESSOR PACK ITEM NUMBERS					EP6U (EP6HD)						
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE					
				4321							
4.2 HT SUCTION PRESSURE CONTROL											
Note, HT suction control is enabled only when there are HT compressors selected in section 5.2 using item 2x5.											
50	HT suction pressure setpoint				5 - 60	25					
153	Optimised HT suction setpoint										
154	Optimised HT suction setpoint upper limit				15 - 60	40					
53	HT suction pressure deadband				0 - 10	5					
54	HT suction pressure increase time constant				1 - 60	30					
55	HT suction pressure decrease time constant				1 - 60	15					
58	HT suction 1st stage hold on				2 - 60	10					
192	Integrated HT pressure error										
51	No of HT suction steps loaded										
197	Low HT suction pressure safety shutdown level (v0.00.8 on)				10 - 40	20					
59	HT suction total capacity loaded (in kW)										
183	HT suction increase next step (kW)										
184	HT suction decrease next step (kW)										
205	Forced number of HT suction stages				0 - 40						
103	Maximum number of HT compressors allowed				1 - 10	10					
104	Number of HT compressors running										

JTL COMPRESSOR PACK ITEM NUMBERS					EP6U (EP6HD)						
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE					
				4321							
4.3 SATELLITE SUCTION PRESSURE CONTROL											
Note, Satellite suction control is enabled only when there are satellite compressors selected in section 5.2 using item 2x5.											
70	Satellite suction pressure setpoint				-5 to + 50	2					
155	Optimised satellite suction setpoint										
156	Optimised Satellite suction setpoint upper limit				5 - 50	10					
73	Satellite suction pressure deadband				0 - 10	5					
74	Satellite suction pressure increase time constant				1 - 60	30					
75	Satellite suction pressure decrease time constant				1 - 60	30					
78	Satellite suction 1st stage hold on				- 5 to + 50	0					
194	Satellite suction										
71	No of Satellite suction steps loaded										
198	Low satellite suction pressure safety shutdown level (v0.00.8 on)				-5 to 10	0					
79	Satellite suction total capacity loaded (in kW)										
187	Satellite suction increase next step (kW)										
188	Satellite suction decrease next step (kW)										
207	Forced number of satellite suction stages				0 - 40						
105	Maximum number of satellite compressors allowed				1 - 10	10					
106	Number of satellite compressors running										
5. COMPRESSOR CONTROL											
Forced functions remain forced if the Maintenance Unit remains plugged in. They are automatically cancelled 30 minutes after the Maintenance Unit is unplugged.											
5.1 COMMON DATA											
200	Number of compressors				0 - 10	10					
201	Number of steps on load										
203	Total capacity loaded (in kW)										
208	Minimum compressor stop time (seconds)				0 - 240	30					
206	Compressor fault alarm delay (mins)				0 - 10	0					
209	Bias loading towards base machine selection	OFF bASE	Disable Enable bias		0 - 1	OFF					
158	Compressor fault repeat alarm delay time (v0.00.8 on)	00:00	Feature disabled		00:00 - 24:00	00:00					
909	Interface baud rate (v0.00.8 on) Note baud rate fixed at 600 baud from v0.01.0	0.6	600 baud								

JTL COMPRESSOR PACK ITEM NUMBERS						EP6U (EP6HD)
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
5.2 COMPRESSOR DATA						
A general form of item numbers for compressors is shown below. The "x" shown in each item number should be replaced by the compressor number. This sequence covers item numbers 210-299 for compressors 1 - 9 and 300 - 309 for compressor 10.						
2x5	Compressor function	0 Lt.C Ht.C SAT.C	Not in use LT HT Satellite		0 - 3	Lt.c
2x3	Compressor status <u>Note:-</u> If more than one input is present, the numbers shown in brackets are added together and displayed instead.	run (128) rdy (64) 0.L (32) Lo.Pr (16) Hi.Pr (8) Oil.F (4) th.Ft (2) 0	Running Ready to run (no faults) Motor overload Low pressure fault High pressure fault Oil pressure failure Motor thermistor fault Off or compressor interface fault			
2x6	Compressor capacity in <u>effective kW</u>				1 - 100	10
2x0	Compressor loading method. From v0.00.8 compressor can be set to unequal capacity steps 66/100%	0 1 2 3 4 5	none 1.Stp 2.StP 3.StP 4.StP 2.Une	not controlled 1 step 2 steps (50/100%) 3 steps (33/66/100%) 4 steps (25/50/75/100%) 2 steps (66/100%)	up to v0.00.7 0 - 4 4.StP v0.00.8 on 0 - 5 4.StP	
2x1	Number of steps on load.					
2x8	Force compressor off	CP.En C.OFF	Compressor enabled to run Forced off			
2x7	Forced number of compressor steps				0 - 4	
2x2	Total running hours (in 10s of hours)				0 - 9999	
37x	Compressor run time last 24 hours (371 for compressor 1 etc)					
2x4	Compressor restart inhibit timer (seconds)					
2x9	Compressor number of starts per hour				4 - 20	10
35x	Average number of starts per hour last 24 hours (351 for compressor 1 etc)					

JTL COMPRESSOR PACK ITEM NUMBERS						EP6U (EP6HD)
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
6. INVERTER DATA (v0.01.0 on)						
330	Select inverter control	OFF In.1S	Not selected Inverter selected		0 - 1	0
151	Optimised suction setpoint (operational)					
153	Optimised HT suction setpoint					
347	Suction pressure error					
344	Inverter capacity loaded in effective kW					
341	Minimum cut out pressure				- 8 to +40	0
340	Time constant				1 - 240	30
339	Speed gain				up to v0.01.1	
					5 - 50	10
					from v0.01.2	
					1 - 250	100
345	Current proportional term					
346	Current Integral term					
331	Number of steps on load	0 127	Off Maximum			
332	Inverter run hours (in 10's of hours)				0 - 9999	
333	Inverter status	rdy	ready to run (Inverter & compressor healthy)			
		run	Compressor running			
		In.Ft	Inverter fault			
		Th.Ft	Motor thermistor fault			
		Oil.F	Oil failure			
		HP(LP)	HP/LP pressure switch fault			
343	Minimum steps allowed		Ph.Ft		1 - 63	1
			O.L			
342	Maximum steps allowed				64 - 127	127
335	Inverter capacity at minimum speed in effective kW				1 - 100	5
336	Inverter capacity at maximum speed in effective kW				1 - 100	10
337	Forced no. of steps				0 - 127	
338	Force inverter off	CP.En C.OFF	Enabled to run Inverter forced off		0 - 1	
909	Interface baud rate (See section 5.3)					

JTL COMPRESSOR PACK ITEM NUMBERS						EP6U (EP6HD)
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
7. DISCHARGE PRESSURE CONTROL						
178	Temperature display unit choice	0 1	CELS FAhr	Celsius Fahrenheit	0 - 1	CELS
60	Discharge pressure setpoint				EP6U	
					100 - 250	200
					EP6UHD	
					100 - 300	275
350	Maximum discharge pressure set point				175 - 250	200
899	Outside temperature					
363	Floating discharge temperature differential	0.0		Function disabled	0 - 15	0.0
364	Effective minimum discharge temperature					
365	Condenser operating temperature					
370	Optimised discharge pressure set point					
394	Analogue/stepped condenser control selection	up to v0.00.5				
		StEP A.LOG	Step control Analogue control		0 - 1	StEP
		v0.00.6 on				
		1 2 3 4	A.LOG CS-A CS-b CS-C	Analogue control Sequence A Sequence B Sequence C	1 - 4	CS-A
63	Discharge pressure deadband				0 - 20	5
395	Analogue fan speed gain				up to v0.00.1	10
					1 - 125	
					from v0.00.2	
					5 - 50	
64	Condenser control time constant				1 - 250	30
65	Discharge pressure to reduce capacity				EP6U	
					140 - 320	300
					EP6UHD	
					140 - 370	350
193	Integrated discharge pressure error					
67	Discharge pressure setpoint offset during gas defrost				0 - 50	0

JTL COMPRESSOR PACK ITEM NUMBERS						EP6U (EP6HD)
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
68	Discharge pressure setpoint offset during heat reclaim				0 - 50.0	0
8 CONDENSER CONTROL						
Forced functions remain forced if the Maintenance Unit remains plugged in. They are automatically cancelled 30 minutes after the Maintenance Unit is unplugged.						
8.1 STEP CONTROL						
390	Number of condenser steps				up to v0.00.7	7
					0 - 13	
					v0.00.8 on	
					0 - 14	
61 (391)	Number of condenser steps running					
392	Forced number of condenser steps				0 - no. of steps (item 390)	
8.2 ANALOGUE CONTROL						
368	Maximum speed at night (%) (v0.00.8 on)				50 - 100	100
369	Select network timer for nighttime definition (v0.00.8 on)	0 1 - 8			0 - 8	0
397	Number of condenser steps in backup analogue mode (from v0.00.2)				0 - 99	0 - 99
392	Forced number of condenser steps				0 - 99	

JTL COMPRESSOR PACK ITEM NUMBERS					EP6U (EP6HD)						
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE					
				4321							
8.3 CONDENSER INPUT & OUTPUT STATUS											
<p>Note 1. If combinations of input or output are present then the value displayed is added up from the individual input/output values as follows:</p> <ul style="list-style-type: none"> 1 Input/Output 1 2 Input/Output 2 4 Input/Output 4 8 Input/Output 5 16 Input/Output 6 32 Input/Output 6 64 Input/Output 7 											
<p>Note 2. From v0.00.6 the normal combinations are displayed as shown below.</p>											
389	Output status interface 1 (v0.00.6 on)	1 1 - 2	Input/output								
388	Output status interface 2 (v0.00.6 on)	1 - 3 1 - 4									
396	Input status interface 1	1 - 5 1 - 6									
387	Input status interface 2 (v0.00.6 on)	1 - 7 1 - 2.7 1 - 3.7 1 - 4.7 1 - 5.7	1 on 1 & 2 on 1, 2 & 3 on 1, 2, 3 & 4 on 1, 2, 3, 4 & 5 on 1, 2, 3, 4, 5 & 6 on 1, 2, 3, 4, 5, 6 & 7 on 1 & 7 on 1, 2 & 7 on 1, 2, 3 & 7 on 1, 2, 3, 4 & 7 on 1, 2, 3, 4, 5 & 7 on								
909	Interface baud rate (see section 5.1) (from v0.00.8)										

JTL COMPRESSOR PACK ITEM NUMBERS					EP6U (EP6HD)	
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
9. INPUTS AND OUTPUTS						
20	Operating mode (v0.00.2 on)	oFF Auto	Manual Automatic			
170	Input states	iP - - iP 1 - iP - 2	No input Input 1 Input 2			
171	Auto/manual (IP-1)	OFF Auto	Manual (pack controller dormant) Auto mode			
172	Liquid level (IP-2)	CLr Lo.Li	Liquid o.k. Low liquid level			
175	Low level liquid alarm delay (minutes)				15 - 240	30
393	Heat reclaim input	OFF Hr.On	Heat reclaim off Heat reclaim on			
160	Watchdog output (LN/LD-2) (Item 169=CPnH)	OFF On	Watchdog fail Watchdog healthy			
161	Gas dump valve output (LN/LD-1) (Item 169=CPnC)	OFF v.on	Off Dump valve on			
162	Gas regulator valve output (LN/LD-2) (Item 169=CPnC or CPnA)	OFF Gr.on	Off Gas regulator on			
163	Differential pressure output relief valve control (LN/LD-1) (item 169=CPnH)	Gd no.Gd	Gas defrost (Diff. pressure) No gas defrost (Diff. pressure relief)			
164	Cool gas valve output (LN/LD-2) (item 169=CPnL)					
165	Interstage valve output (LN/LD-2) (Item 169=CPnA)	OFF IS.on	Off Interstage valve on			
166	Liquid valve output (see item 168) LN/LD-1 (item 169=CPnL)	OFF Li.on	Off Liquid valve energised			
168	Liquid line valve type	n.c n.o	Normally closed Normally open		0 - 1	n.c
169	Output function selection	nonE CPnH CPnC CPnA CPnL	Disabled Differential valve & watchdog Dump valve & Gas regulator Interstage valve & Gas regulator Differential valve & Cool Gas valve		0 - 4	CPnH
145	Interstage interlock selection	OFF IL.En	Interlock disabled Interlock enabled		0 - 1	OFF
66	Gas temperature to open regulator valve				25 - 40	30

JTL COMPRESSOR PACK ITEM NUMBERS					EP6U (EP6HD)						
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE					
				4321							
10. DEFROST CONTROL											
10.1 COMMON DATA											
400	Number of defrost systems				0 - 28	28					
401	Maximum gas defrost duration Note: Off cycle defrosts as assumed to be longer than this setting				15 - 40	25					
402	Time before next gas defrost due				0 - 5	0					
403	Time before end of gas defrosts				0 - 5	0					
404	Maximum number of gas/electric defrosts allowed at any time				1 - 28	3					
398	Jnet network defrost arrangement	nonE PrEd dEFS	No scheduling Predict scheduler Time scheduler								
399	JTL Predict defrost controller present on network	oFF PrEd	Not present Present								
176	Defrost scheduling operation in manual	Auto MAn	Enabled in auto only Enabled always		0 - 1	Auto					
177	JTL numbering on systems on defrost display Note: Depends on unit no setting on item 1.	oFF J.no	System no. range 1- 28 System no. range x01 - x28		0 - 1	oFF					
405	Evaporator inhibit defrost function selection	OFF En.El	Disable Inhibit enabled		0 - 1	OFF					
406	Select defrost relay termination at beginning or end of drain down period	OFF t.End.	Relay terminates at beginning of drain down Relay terminates at end of drain down		0 - 1	OFF					
407	Group interface selection	OFF CG.On	Group interface not used. Group interface used for differential pressure control.		0 - 1	OFF					
408	Drain (bleed) down interface selection	OFF dd.On	Drain down interfaces not used. Drain down interfaces used for drain down control.		0 - 1	OFF					
409	Stub defrost interfaces selection	OFF Sb.On	Stub interfaces not used. Stub interfaces used for defrost control.		0 - 1	On					

JTL COMPRESSOR PACK ITEM NUMBERS					EP6U (EP6HD)	
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
10.2 DEFROST DATA						
410	Start time for first daily defrost	SYSTEM				
420		1		00:00 -	08:00	
430		2		23:59	08:30	
440		3			09:00	
450		4			09:30	
460		5			10:00	
470		6			10:30	
480		7			11:00	
490		8			11:30	
500		9			12:00	
510		10			12:30	
520		11			13:00	
530		12			13:30	
540		13			08:15	
550		14			08:45	
560		15			09:15	
570		16			09:45	
580		17			10:15	
590		18			10:45	
600		19			11:15	
610		20			11:45	
620		21			12:15	
630		22			12:45	
640		23			13:15	
650		24			13:45	
660		25			08:00	
670		26			09:00	
680		27			10:00	
		28			11:00	

JTL COMPRESSOR PACK ITEM NUMBERS					EP6U (EP6HD)	
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
<p>A general form of item numbers for defrost systems is shown below. The "x" shown in each item number should be replaced by the system number up to system 9. Systems 10-19 use items 500-599 and systems 20-28 use items 600-689. Forced functions remain forced if the Maintenance Unit remains plugged in. They are automatically cancelled 30 minutes after the Maintenance Unit is unplugged.</p>						
4x1	Defrost duration (mins)				5 - 60	20
4x2	Defrost pattern	0 1 - 6 7 8	No defrosts. Number of equally spaced daily defrosts. 3 defrosts per day, but the 3rd is missing. 4 defrosts per day, but the 4th is missing.		0 - 8	4
4x3	Forced defrost	OFF Fd.on	No forced defrost Forced defrost on		0 - 1	
4x4	Forced refrigeration	OFF Fr.on	No forced refrig. Forced refrig. on		0 - 1	
4x5	Defrost mode	0 deF dr.dn F.dEF F.rEF d.inH FAIL	Refrig. Defrost Drain down Forced defrost Forced refrig. Defrost inhibited Defrost interface fail			
4x6	Drain down duration				0 - 15	5
4x7	Compressor group associated with this defrost system	0 Lt.C Ht.C Sat.C	No association Lt compressor group Ht compressor group Satellite compressor group		up to v0.00.6	
					0 - 3	0
					from v 0.00.7	
					0	0
4x8	No of evaporators on this defrost system	0 1 - 10	Defrost terminated on time only. JTL units terminate defrost on temp. and inform pack.		0 - 10	0
4x9	No of JTL-controlled evaporators terminated					

JTL COMPRESSOR PACK ITEM NUMBERS					EP6U (EP6HD)	
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
11. DISPLAY FUNCTIONS						
138	Display configuration	0 1 2 3	4 pressures displayed on LED display 4 pressures, No of compressors running, No of condenser step systems on defrost shown on LED display 4 pressures & systems on defrost shown on LED display. Reserved		0 - 3	1
139	Display type selection (v0.00.1 - v0.00.6) NOTE: This item is not operational and should be set at LEd.2	LEd.1 LEd.2	(not allowed) 4 displays		0 - 1	LEd.2
177	JTL numbering on systems on defrost display Note: Depends on unit no setting on item 1.	oFF J.no	System no. range 1- 28 System no. range x01 - x28		0 - 1	oFF
179	Pressure display unit choice	PSI bAr PASC	p.s.i. bar kPa		1 - 3	PSI
12. CLOCK CALENDAR						
Note. The time and date can be displayed as standard or daylight saving (summer) time. This choice is made on item 18. When daylight saving is chosen and the controller is connected to a JTL Network Controller supporting daylight saving operation, the change is made automatically to the current EU directive.						
2	Time of day				00:00 - 23:59	
3	Day of week	Sun - Sat	0 = Sunday 1 = Monday etc			
4	Date				01:01 - 31:12	
5	Year				up to v0.00.6 1992 - 2022 from v0.00.7 2004 - 2034	
18	Daylight saving enable	Stnd dAY.S	Standard time Daylight saving time		0 - 1	Stnd

JTL COMPRESSOR PACK ITEM NUMBERS					EP6U (EP6HD)	
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
13. RESTORE FACTORY DEFAULTS						
9	Set default values To set the factory defaults into the memory of the controller, set item 9 to the set default value of "1234". This should be done on initial commissioning of the unit or when the unit is being installed as a replacement part.	1234 1066	Load default settings Write to NVRAM immediately			
14. RESTORE PARAMETERS FROM NETWORK (from v0.01.0)						
To restore the data from the network first set appropriate unit number on item 1. Then check item 965 to see if this facility is available on the network. The information on item 965 is received from a network broadcast every few minutes. If the restore parameter facility is available and operational then item 965 will be set to a non zero number e.g. 2. To request restore parameters set item 964 to 1234. Item 963 displays the parameter restore progress. When all parameters are downloaded item 964 is cleared to 0.						
965	Master database port	0 1 - 4	Not in use NC port no			
964	Set restore parameters from network	1234	Request restore			
963	Parameter restore progress	rdy dnl.r din.p dnl.c FAIL	Restore function possible Restore requested Restore in progress Restore complete Restore fault			
959	Requested template	0 1-9999	As commissioned Template number		0 - 9999	
15. SYSTEM ALARMS						
80	Group alarm 81 - 88	0 1 - 255	No alarms Check 81 - 88			
81	High LT suction pressure	CLr Hi.Lt	No fault Fault			
82	High HT suction pressure	CLr Hi.Ht	No fault Fault			
83	High discharge pressure	CLr Hi.dP	No fault Fault			
84	High Satellite suction pressure	CLr Hi.St	No fault Fault			
85	Refrigerant loss	CLr Lo.Li	No fault Fault			
86	Motor thermistor fault	CLr Th.Ft	No fault Fault			
87	Motor overload fault	CLr OL	No fault Fault			
88	Condenser fault	CLr Fn.Ft	No fault Fault			
90	Group alarm 91 - 98	0 1 - 255	No alarms Check 91 - 98			
91	Pressure transducer fault	CLr Pt.Ft	No fault Fault			

JTL COMPRESSOR PACK ITEM NUMBERS					EP6U (EP6HD)	
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
92	Thermistor fault	CLr th.Ft	No fault Fault			
93	Thermistor excitation voltage (Mk1 assemblies only)	CLr PS.Ft	No fault Fault			
94	High or low pressure switch fault	CLr HP.LP	No fault Fault			
95	Defrost interface card fault	CLr Stub	No fault Fault			
96	Compressor interface card fault	CLr CP.F	No fault Fault			
97	Compressor fault OR Auto input not present	CLr CPr.F	No fault Fault			
98	Oil pressure fault	CLr OIL.F	No fault Fault			
900	Group alarm 901 - 908 v0.00.8 on)	0 1 - 255	No alarms Check 901 - 908			
901	Compressor 1 fault v0.00.8 on)	CLr C1.F	No fault fault			
902	Compressor 2 fault v0.00.8 on)	CLr C2.F	No fault fault			
903	Compressor 3 fault v0.00.8 on)	CLr C3.F	No fault fault			
904	Compressor 4 fault v0.00.8 on)	CLr C4.F	No fault fault			
905	Compressor 5 fault v0.00.8 on)	CLr C5.F	No fault fault			
906	Compressor 6 fault v0.00.8 on)	CLr C6.F	No fault fault			
907	Compressor 7 fault v0.00.8 on)	CLr C7.F	No fault fault			
908	Compressor 8 fault v0.00.8 on)	CLr C8.F	No fault fault			
910	Group alarm 910 - 918 v0.00.8 on)	0 1 - 255	No alarms Check 910 - 918			
911	Compressor 9 fault v0.00.8 on)	CLr C9.F	No fault fault			
912	Compressor 10 fault v0.00.8 on)	CLr C10.F	No fault fault			
915	Auto input not present (PLANT FAULT) v0.00.8 on)	CLr P.Flt	No fault fault			
917	Phase failure fault (v0.01.0 on)	CLr Ph.FL	No fault fault			
918	Compressor inverter fault (v0.01.0 on)	CLr In.FL	No fault fault			

JTL COMPRESSOR PACK ITEM NUMBERS					EP6U (EP6HD)	
ITEM	DESCRIPTION	CODE	CODE MEANING	BIT	RANGE	ITEM 9 VALUE
				4321		
16. DIAGNOSTIC & TEST FUNCTIONS						
6	JTL Network communications speed	4.8 38.4	Kilo Baud Kilo Baud			
7	Communications method	HALF	2 wire			
967	Latest unit no polled on zone					
973	Latest polling interval This time shows the polling interval between the last two successful network awake messages to this unit.	min:sec				
974	Time since last awake message	min:sec				
975	Network receive timer Each time a message is read correctly the timer is set to 10 it counts down. If the timer reaches 0 then the communications module is reset.	seconds	(counts down to 0)			
976	Network receive bad character counter. The counter counts down from a preset number. When the counter reaches 0 the communications module is reset.		(counts down to 0)			
977	Transmit control line status for the operation of the Jnet network communications.	Hi Lo	Transmit Receive			
8	Bitswitch Setting		Unused			
89	Thermistor excitation value (Factory test)		Not used			
99	Test digital displays	CLr SEt	Not active Test active		0 - 1	
100	Test inputs	- - - 1 - - - - 2 - -	No inputs Input 1 on Input 2 on			
199	Test relay outputs	clr SEt	Not active Active		0 - 1	
10	Processor alarms (11 - 17)	0 1 - 255	No alarms Check 11 - 17			
11	Static RAM fault	CLr rA.Ft	No fault Fault			
12	Program/counter fault	CLr PC.Ft	No fault Fault			
13	Stack pointer fault	CLr SP.Ft	No fault Fault			
14	Background loop fault	CLr bL.Ft	No fault Fault			
15	PROM checksum fault	CLr Pr.Ft	No fault Fault			
16	NVRAM fault	CLr n.Ft	No fault Fault			
17	Instruction TRAP fault	CLr tP.Ft	No fault Fault			

DISPLAY DATA		EP6U (EP6HD)
NORMAL DISPLAY		
999.9	Pressure in psi	
--	Not selected	
ALARM TEXT (in descending priority order)		
P.FLd	Plant failed	
Hi.dP	High discharge pressure	
Stub	Defrost interface fault	
rEF.L	Refrigerant loss	
CPr	Compressor fault	
FAn	Condenser fan problem	
Hi.Lt	High LT suction pressure	
Hi.Ht	High HT suction pressure	
Hi.St	High satellite suction pressure	
Hi.dt	High discharge temperature	
OTHER TEXT		
JTL	Start-up text	
Lt	LT suction pressure follows this text	
Ht	HT suction pressure follows this text	
SAt	Satellite suction pressure follows this text	