

ND440 ITEMO										
	NR110 ITEMS									
UNIT NO.		1	Select a unit number of a physically adjacent unit to the NR110 to enable easy location eg if under cabinet 153 the number should be 153.X							
P1	Pressure Set A	210	Enter Pressure Set Number (see note 1)							
	Pressure Set B	211	Enter Pressure Set Number (see note 2)							
P2	Pressure Set A	220	Enter Pressure Set Number (see note 1)							
	Pressure Set B	221	Enter Pressure Set Number (see note 2)							
Pressure Broadcast 1	Pressure Set	601	Enter Pressure Set Number (see note 3)							
Pressure Broadcas	Pressure Set	701	Enter Pressure Set Number (see note 3)							

DESCRIPTION

ISSUE

NOTES:

- 1. Pressure set number A for pack would typically be the pack number eg for pack 200.0 the pressure set should be set as 200.
- 2. Pressure set number B Set to 0.
- 3. Pressure set number for the pack associated with the broadcast pressure. If unused set the value to 0.

JTL SYSTEMS LTD.

THIS IS AN UNCONTROLLED COPY - UNLESS STAMPED WITH CONTROLLED COPY STAMP

APP'D DATE

				/jtl)	41 KINGFISHER COURT, HA NEWBURY, BERKSHIRE. R		}E RD,	
1	ORIGINAL ISSUE	MJK	08/16		TEL: 01635-263646 FAX: 010	635 2636	47	
Dragging over ID Cohema using ND110 Medules			SCHEMATIC DIAGRAM					
			PROJ:	DRG No:	SHT	OF	ISS.	
					04703	1	1	1