

NOTES:

- 1. THE LCPN CONTROLLER MUST BE EARTHED TO THE CHASSIS VIA THE CONTROLLER FIXING HOLE AS SHOWN.
- 2. TO MEET EMC REQUIREMENTS THE CONTROLLER MUST BE INSTALLED ACCORDING TO THE INSTALLATION REQUIREMENTS SHEET FOR THIS PRODUCT.
- 3. INPUTS REQUIRE `C' CONNECTED TO NEUTRAL AND THE INPUT TO 230Vac WHEN SIGNAL IS PRESENT.
- 4. PLANT INPUTS TO CON B MUST BE ON THE $\underline{\sf SAME}$ PHASE AS THE SUPPLY ON CON1 (CON A).

THIS UNIT IS NOT RATED FOR 415V

- 5. FANS/HEATER OUTPUT SELECTABLE USING MAINTENANCE UNIT.
- 6. THE DEFROST OUTPUT HAS CHANGEOVER CONTACTS. SELECT THE APPROPRIATE OUTPUT FOR THE APPLICATION.



JTL SYSTEMS LTD

41 KINGFISHER COURT, HAMBRIDGE RD, NEWBURY BERKSHIRE: RG14 5SJ TEL: 01635 263646 FAX: 01635 263647

	ISS	DESCRIPTION	APP'D	DATE
	3	REMOVED CONVERTER BOARD	MJK	9/01
	2	SWAPPED INPUTS	MJK	3/01
١	4	UPDATED & ADDED TEMP SENSOR CONNECTIONS	MJK	12/02

CABINET CONTROLLER
CONNECTIONS

TYPE: LCPN

J. LC DRG No: 02534 SHT OF 1 1

THIS IS AN UNCONTROLLED COPY - UNLESS STAMPED WITH CONTROLLED COPY STAMP