


## NOTES:

- THE LACN CONTROLLER MUST BE EARTHED TO THE CHASSIS VIA THE CONTROLLER FIXING HOLE AS SHOWN.
- 2. TO MEET EMC REQUIREMENTS THE CONTROLLER MUST BE INSTALLED ACCORDING TO THE INSTALLATION REQUIREMENTS SHEET FOR THIS PRODUCT.
- 3. INPUTS REQUIRE `C' CONNECTED TO NEUTRAL AND THE INPUT TO 230Vac WHEN SIGNAL IS PRESENT.
- PLANT INPUTS TO CON2 MUST BE ON THE <u>SAME</u> PHASE AS THE SUPPLY ON CON1.

THIS UNIT IS NOT RATED FOR 415V

- 5. THE DEFROST OUTPUT HAS CHANGEOVER CONTACTS.
  SELECT THE APPROPRIATE OUTPUT FOR THE APPLICATION.
- 6. TO ENSURE THAT INTERNALLY FITTED SUPPRESSORS WORK CORRECTLY:-ENSURE THAT THE LINE VOLTAGE IS CONNECTED TO TERMINALS 'LN' AND EACH LOAD IS CONNECTED TO TERMINALS MARKED 'NO' OR 'NC.'
- 7. USE ITEM 138 TO SELECT INPUT FUNCTION.
- 8. LCD13 SUPPORTED FROM VERSION 0.00.5 FIRMWARE.



03099

1

THIS IS AN UNCONTROLLED COPY - UNLESS STAMPED WITH CONTROLLED COPY STAMP